


## Before you hit the ice...

Read the important information in this pamphlet and register your purchase for warranty activation at [thermablade.com](http://thermablade.com).

Also, take a moment to familiarize yourself with your new blades:



## 4 Tips for first use

By reducing friction, heated skate blades can provide numerous benefits for skaters of all abilities including :

- Tighter turns
- Quicker starts
- Longer strides
- Less fatigue

In order to fully appreciate and get used to these benefits, we recommend that you try the following for the first hour that you use them:

1. OFF for the first 20 minutes
2. ON for the next 20 minutes
3. OFF for the last 20 minutes

NOTE: Because heated skate blades improve grip on all ice surfaces, we recommend a shallower hollow than average to maximize glide. Consult your trusted pro shop for more details on how to optimize your new blades.

## 1

### Install and sharpen your new blades on your favorite hockey boots

#### Installation:

Thermablade™ skate blades are installed in the same manner as any other skate blade and should only be done by an authorized Thermablade™ dealer.

#### Sharpening:

Sharpen like any other hockey skate blade. We recommend going to a reputable dealer to ensure proper sharpening care and quality.

## Charger Indicator Lights

With No Blades Plugged In	
Green	Charger on

With Blades Plugged In	
Red	Charging
Green	Charging Complete

#### Tips for maximum battery charge:

1. Make sure your blades are turned off when charging
2. Charged for a full 120 minutes the same day you use them
3. During the off season, store blades fully charged and re-charge every 60 days

## 2

### Charge the batteries using the supplied charging unit.

- Plug the wall adapter into the charging unit (LED = Green)
- Plug each blade to its corresponding LEFT/RIGHT cable (LED = RED)
- After approximately 2 hours charging is complete (LED = GREEN)



## Storage and Cleaning

- To optimize product life, store your blades fully charged, turned off and disconnected from the charger in a dry place at room temperature.
- Clean the parts as needed with a soft, slightly damp cloth and a mild cleanser. Always unplug the charger from the outlet before cleaning it.

#### Battery Disposal:

- Thermablade™ heated skate blades contain batteries that may not be disposed of in household trash. Simply return used batteries to any authorized Thermablade™ dealer for disposal in accordance with the guidelines of the RBRC (Rechargeable Battery Recycling Corporation).



## 3

### Turn your blades ON

Simply press the inside and outside of the rear of each holder at the centre of the logos with your **thumb** and **index finger** for a minimum of 3 seconds. A red light will come on to confirm that the blades are functioning correctly. To turn them off, simply repeat the above step.



## Operating Tips

- Charge your Thermablades™ after every use. This will maintain the battery and keep the device ready for use at all times.
- Your new blades can be in any operating mode when starting the charging process. (POWER OFF, STAND-BY, IN USE)
- Blades can remain on the charger for extended periods without damage to the batteries.
- The battery may only be replaced by an authorized Thermablade™ dealer.
- To optimize battery life during a game, ensure that your blades are free from excessive snow build-up especially when you're sitting on the bench.
- The battery slowly discharges even when switched off. In order to extend the life of the battery and avoid damage, we recommend charging the battery after every use. If stored for longer periods (such as in the off season), it is recommended the battery be charged at least every 8 weeks.